John Lewis

Stock Code: 803/60806, 803/60506.

### Ashton Bunk Bed Bed

Thank you for purchasing this Ashton Bunk Bed. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



For product support or spare parts please call the John Lewis Helpline;

> T: 01244 689949 E: mail@fwgroup-uk.com

### Pre - assembly Preperations

Please ensure that all instructions are read in full before attempting to assemble this product.



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis helpline.

This product is **HEAVY**, it should be assembled as near to the point of use as possible. **TAKE CARE WHEN LIFTING** to avoid personal injury (or) damage to the product.

This product takes approximately **60 MINUITES** to assemble with **2 PEOPLE**.


# The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

If you require any additional information or have any issues with this product please call the John Lewis helpline on 01244 689949 or email mail@fwgroup-uk.com

### Fittings and parts checklist


NO	Hardware List Description		QTY
A		ALLEN KEY M4	1 PC
В		BARREL NUT M6	16 PCS
С		CSK WOODEN SCREW M4 X 32MM	72 PCS
D	•	Bolt M6 x 100MM	22 PCS
E		Bolt M6 x 40MM	8 PCS
F	•	Bolt M6 x 30MM	6 PCS
G		WOOD DOWEL M8X30MM	4 PCS
н	0	STEEL PIN M10X100MM	4 PCS
NO	Parts List Description		QTY
1	HEADBOARD TOP		2 PCS
2	HEADBOARD BOTTOM		2 PCS
3	SHORT GUARD RAIL		1 PC
4	LONG GUARD RAIL		1 PC
5	LADDER LONG		1 PC
6	LADDER SHORT		1 PC
7	LADDER HORIZONTAL		4 PCS
8	SIDE RAIL TOP FRONT		1 PC
9	SIDE RAIL TOP BACK		1 PC
10	SIDE RAIL BOTTOM FRONT		1 PC
11	SIDE RAIL BOTTOM BACK		1 PC
12	SLAT		36 PCS

### Fittings and parts checklist



#### Step 1


Insert Barrel Nut (B) into the Side Rail Bottom Front (10) and Side Rail Bottom Back (11). Attach the Headboard Bottom (2) using Bolt M6 x 100mm (D) and tighten using Allen Key M4 (A). Repeat this process at each end of the bed as shown in the diagram below.



**Please Note:** One of the bottom Side Rails (10) and one of the Top Side Rails (8) have additional pre-drilled holes for the Ladder to bed attached meaning the **Ladders can be placed on either end of the bed** so you need to decide the positioning before starting to assemble the bed.

#### Step 2


Starting at one of the bed, secure the first fitted slat into place using Screw (C). Next, secure the fitted slat to the other end and secure using Screw (C) ensuring that there are no no gaps between the slats and the Headboards. Finally secure the rest of the slats into place using Screw (C) as shown in the diagram below using a Phillips Head Screwdriver.



**Please Note:** The slats at each end have been cut to allow them to sit flush with NO GAPS between the headboard and slats.


#### Step 3

Insert Barrel Nut (B) into the Side Rail Top Front (8) and Side Top Back (9). Attach To the 2 Headboard Top (1) using Bolt M6 x 100mm (D) and tighten using a Phillips Head Screwdriver as shown in the diagram below. Repeat this process at each end of the bed as shown below.



#### Step 4


Starting at one end of the bed, secure the first fitted slat into place using Screw (C). Next secure the fitted slat to the other ebd using Screw (C) ensuring that there are no gaps between the slats and headboard. Finally secure the rest of the slats into place using Screw (C) and a Philips Head Screwdriver as show in the diagram below.



**Please Note:** The slats at each end have been cut to allow them to sit flush with NO GAPS between the headboard and slats.

#### Step 5


To join the upper bed to the bottom bed insert a Steel Pin (H) into the top four corner posts of the bottom bed, carefully lift upper bed structure and gently lower onto the Steel Pin (H) as shown in the diagram below.



**Please Note:** The grooved lines indicate the point in which the mattress shoud not exceed. The maximum height of the mattress for this bunk is 19cm. Recommended size is: L: 190cm x W: 90cm x H: 19cm (max).

### Step 6

Attach Ladder Horizontal (7) to the Ladder Long (5) using bolt M6 x 40mm (E) and tighten using Allen Key M4 (A). Repeat this step to attach the Ladder Short (6) to the Ladder Horizontal (7).



**Please Note:** The ladders can be placed either side of the bunk, choose which side you want the ladders before attaching the Side Rail.

Step 8

Secure the Long Guard Rail (4) using bolt M6


x 100mm (D) to both Headboard Tops (1) and

tighten using Allen Key M4 (A). Then secure the

Short Guard Rail (3) to Headboard Top (1) using


#### Step 7

Insert Dowel M8 x 30mm (G) into the bottom of the Short Guard Rail (3) and Long Guard Rail (4). Then attach the Rails (3) and (4) to Side Rail Top Back (8) and Short Guard Rail (3) using the holes for the Dowels as a guide.



#### Step 9

Attach assembled Ladder Unit to the Short Guard Rail (3), Side Rail Top Front (8) and Side Rail Bottom Front (10). Secure the Ladder Unit using bolt M6 x 30mm (F) and tighten using Allen Key M4 (A) as shown in the diagram below.



Please ensure all fittings are securely tightened before use.

**WARNING:** Children can become trapped between the bed and the wall. To avoid risk of serious injury the distance between the wall and the top safety barrier should be less than 75mm or more than 230mm.

#### **Care and Maintenance**

#### **Wood Furniture**

Wood displays different grain patterns depending on which way they are cut - for example, 'the medullary ray' which can appear on oak furniture as a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow distintive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been prieviously purchased.

#### How to care for your wood furniture

Furniture with a hard laquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its luster.

Spray polishes are best avoided as they contain sillicones which may spoil the furniture by building up over time.

Our furniture will endure most temperatures in teh home but it is best to avoid placing furniture next to heat sources such as radiators or fires. be particulary careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

### Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competant adult. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture. During assembly children should be kept away from the product due to possible risk of injury. Do not use this item if any components are missing or damaged.

It is recommended that before moving heavy objests to a new location they are completly dis-assembled to avoid personal injury or damage to teh furniture. Please be careful to retain all fittings when doing this.

#### This product is suitable for children aged 3 - 12 years. The maximum weight or load for this product is 70kg.

This product complies with BS EN 747:2007 and Entrapment Hazard Safety Regulations 1987.

If you require any additional information or have any issues with this product please call the John Lewis helpline on 01244 689949 or email mail@fwgroup-uk.com